


















<p>20</p>  <p>BC - Ball Connector</p>	<p>36</p>  <p>CA - Connector Arm</p>
<p>Tall Medium Short</p> <p>12 12 24</p> <p>Adjustable Ball Joints</p>	<p>1</p>  <p>Upper Ball Return</p>
<p>1</p>  <p>Upper Chain Sprocket</p>	<p>162</p>  <p>Chain</p>
<p>1</p>  <p>Chain Motor Assembly</p>	<p>16</p>  <p>Ball Carrier</p>
<p>4</p>  <p>B - Bell</p>	<p>2</p>  <p>CB - Catch Basket</p>
<p>2</p>  <p>TR - Trampoline</p>	<p>*</p>  <p>Chimes</p>
<p>1</p>  <p>V Vortex</p>	<p>*</p>  <p>Ball Trap</p>
<p>1</p>  <p>XY - Xylophone Key</p>	<p>1</p>  <p>XY BT - Xylophone Ball Trap</p>

HI-RISE FRAMEWORK






TOP VIEW SECTION **A**




TOP VIEW SECTION **B**



TOP VIEW SECTION **C**



TOP VIEW SECTION **F**




TOP VIEW SECTION **G**



TOP VIEW SECTION **H**



TOP VIEW SECTION **I**



1 - Indicates number of pieces in your Chaos set.

* - Part does not come in your Chaos set. Visit our web site at www.chaostoy.com and we will show you how to get one.

chaosTM
WORLD OF MOTION

www.chaostoy.com
Phone: (314) 503-4488 • Fax: (314) 991-1722